




Monitor Mount - B1

Инструкция за монтаж



- M4x12MM A(4PCS) M5x12MM B(4PCS) M6x20MM C(3PCS) M6x10MM D(2PCS)
- ø6.5xø13x2 E(8PCS) 4X4MM F(1PC) 5X5MM G(1PC)

1. Капак на тръбата (1PC)
2. Планка за екрана (1PC)
3. Фиксиращ пръстен(1PC)
4. Тръба (1PC)
5. Организатор на кабели 1 (1PC)
6. Долна подпора(1PC)
7. Планка (1PC)
8. Гумена подложка (1PC)
9. Организатор на кабели 2 (2PCS)
10. Декоративен капак(1PC)
11. 2.5*2.5 ключ (1PC)



VESA
75x75
100x100


17°~30°

10kg

-85° ~15°


STEP1

Опция 1: скоба




STEP2

Инсталиране на планката за екрана




STEP3

Прикачване на екрана за планката



STEP4

Регулиране на екрана



ВНИМАНИЕ

- Този продукт съдържа малки предмети, които биха могли да представляват опасност от задавяне при поглъщане. Дръжте тези елементи далеч от малки деца.
- Уверете се, че тези инструкции са прочетени и напълно разбрани преди да се опитате да инсталирате.
 - Бюрото или монтажната повърхност трябва да могат да поддържат комбинираното тегло на монтажа и дисплея, в противен случай конструкцията трябва да бъде подсилена.
 - Проверявайте частите на ставите на всеки два месеца, като се уверите, че винтовете са разхлабени или не.

Този продукт е проектиран за инсталиране на бюрото. Преди да инсталирате, уверете се, че монтажът ще поддържа комбинирания товар на оборудването и хардуера. Никога не надвишавайте максималната товароносимост 10 KG, иначе може да доведе до повреда на продукта или до телесни наранявания.

Забележка: Този продукт е предназначен само за вътрешна употреба. Използването на този продукт на открито може да доведе до повреда на продукта или до лично нараняване.





Monitor Mount - B1

Installation guide



- M4x12MM A(4PCS) M5x12MM B(4PCS) M6x20MM C(3PCS) M6x10MM D(2PCS)
- ø6.5xø13x2 E(8PCS) 4X4MM F(1PC) 5X5MM G(1PC)

1. Tube cover (1PC)
2. TV plate (1PC)
3. Fixing ring (1PC)
4. Tube (1PC)
5. Cable management 1 (1PC)
6. Bottom support (1PC)
7. Knob (1PC)
8. Anti-slip rubber (1PC)
9. Cable management 2 (2PCS)
10. Decorative Cover (1PC)
11. 2.5*2.5 wrench (1PC)



VESA
75x75
100x100


17°~30°

10kg

-85° ~15°

STEP1


OPTION 1: Clamp



4x4mm
F

STEP2


Install TV plate



2.5X2.5mm


STEP3

Attaching screen to TV plate



STEP4

Adjusting screen



CAUTION

- This product contains small items that could be a choking hazard if swallowed. Keep these items away from young children.
- Make Sure these instructions are read and completely understood before attempting installation. If you are unsure of any part of this installation, please contact a professional installer for assistance.
 - The desk or mounting surface must be capable of supporting the combined weight of the mount and the display, otherwise the structure must be reinforced.
 - please check joint parts every two months, making sure the screws are loosened or not.

This product was designed to be installed on desk. Before installing, make sure the mount will support the combined load of the equipment and hardware. Never exceed the maximum load capacity 10 KG, or else it may result in product failure or personal injury.

Note: this product is intended for indoor use only. Use of this product outdoors could lead to product failure or personal injury.